
Numatic

The Mopmatic pre-prepared dual mopping systems explained.

MopMatic is a unique mop preparation system that allows operators to have an almost constant supply of clean, uniformly impregnated mops to carry out the task in hand. Whether the need is for cleaning or disinfecting or a combination of the two, uniformly prepared mops leave nothing to chance.

1 Load the mop box with 10 clean mop heads (pockets up).



2 Close lid, push firmly on lid and lock over all 3 latches. Ensure all latches lock down fully.



3 Turn box on it's side and open sliding door of dispensing reservoir.



4 Pour 2 litres of the approved solution in to the dispensing reservoir.



5 Close the sliding door and leave to soak for 10 minutes.



6 Return pail to the lid up position, open lid and use Numatic Wing mop to remove mop head (hands free).



7 Push down to fully engage mop head on to wing mop.



8 After use, place mops in appropriate dirty mop container (hands free).

Bucket can hold approximately 20-25 dirty mops.

